



VANITY TOP INSTALLATION

WARNING

Inspect product before installation and immediately report any damage.

Marbelite Corporation is not responsible for damages incurred after installation.

1. Test fit lavatory to cabinet for size and overhang.
2. Remove lavatory and install faucets.
3. Place a dab of construction adhesive or silicone on top corners of cabinet.
4. Set lavatory firmly in place.
5. Connect water supply to faucets.
6. Install drain assembly using silicone.
 - **DO NOT OVERTIGHTEN DRAIN. HAND TIGHTEN—AND GIVE ¼ TURN WITH WRENCH.**
7. Sidesplashes should be test fit and then bonded to the walls with adhesive or silicone.
8. All joints should be sealed with silicone.